

rocket adjusters

Thank you for purchasing this pair of Jagwire Rocket Adjusters™. These handy, lightweight items are designed to install into the shift cable output on Shimano STI™ shifters and provide a convenient place to make precise adjustments to your shifting system.

WARNING: This is a cable-related product that is installed inline in your shift cable system. Failure to install this product properly could cause failure of the shifting system while riding and subsequent injury or death. If you don't fully understand any part of these instructions or don't possess the tools or skills to perform this installation, please pay a professional bicycle mechanic to install this product for you. Your life could depend on it.

Tools needed: Cable and housing cutters, cable removal and installation tools suitable for the bicycle you are working on.

Installation instructions:

1. Remove old shifter cables

We strongly recommend using fresh, new shifter cables with this installation. It isn't absolutely necessary but it makes the installation much easier. Start by removing the existing cables from your STI shifters per Shimano OEM instructions.

2. Install new cables

Install new cables into the STI levers per Shimano OEM instructions. Do not install the housing yet. Grab and gently pull on each shifter cable (one-at-a-time) and press each shift lever button to verify the cable is seated in the lever properly and is at the bottom of its travel.

3. Install Rocket Adjusters

Slide one Rocket Adjuster onto each cable with the tapered rubber end pointing toward the STI shifter. Grab the adjuster with your fingertips and seat the tapered rubber end into the STI shifter's cable output—don't press too hard, the cable and housing will soon hold the Rocket Adjuster in place. Now prepare the adjuster for use by manually turning the adjusting barrel to your desired setting (most people want the adjuster set all the way in).

4. Complete installation

Depending on how worn your shifter housing is, you may also want to replace it at this time. Install housing, affix cables to derailleurs, and adjust the system per Shimano OEM instructions. Keep in mind that it may take a few shifts to fully seat the Rocket Adjuster, and several more to initially stretch the cable.

5. Adjustment

Turn the Rocket Adjuster adjusting barrel clockwise or counter-clockwise as desired to shorten or lengthen the cable. It's that simple!

**For installation
assistance contact
your local bike shop
or email us at:
info@jagwireusa.com**

www.jagwireusa.com