

tube tops 3G

Thank you for purchasing our Jagwire Tube Tops 3G™ frame protectors. These simple little items install over your cable housing and provide a soft bumper to deaden the impact of cables hitting your frame while riding, minimizing rattles and protecting your frame's expensive finish.

Tools and supplies needed: Hands, isopropyl alcohol (optional)

Installation instructions:

Tube Tops 3G feature a split seam that makes them easy to install on any 4 or 5mm cable housing. Determine where your brake or shift cable housing touches the frame, spread the Tube Top open at the seam and slip it over the housing at that point. The Tube Top will close and hold itself in place. Rotate the Tube Top so that the seam faces away from the frame for best results. A squirt of isopropyl alcohol is not necessary but can be helpful in fine-tuning the location of the Tube Top. If you need to adjust the location, simply open the seam, pry the Tube Top off, and try again.

**For installation
assistance contact
your local bike shop
or email us at:
info@jagwireusa.com**

www.jagwireusa.com